

Cable groove moulding

Installation

- See also the general installation instruction of baseboards, which will instruct you how to add length to a baseboard. Also, how to install corners and cut the end of the baseboard.
- In the cable-grooved mouldings of baseboards and architraves, several cables can be run within the moulding, out of the way and out of sight. Power cables can be installed at separately from other cables, in order to lower the risk of interference.
- Place the lower cables next to the wall and fasten the moulding to the wall.
- Press the grooved cover shut. The grooved cover is easy to remove and replace, you can add or remove cables without removing the moulding.